


# Hygienic double blade squeegee

Replacing the replacement cassette is easy.  
Please note the finger grip.

Easy Replacement with finger grip

## Easy to remove



## Easy to replace

Make sure the replacement cassette is placed precisely on top of the squeegee base, when inserting the new cassette.



Visit us at [vikan.com](http://vikan.com)

Vikan A/S Rævevej 1 7800 Skive Denmark  
Tel.: +45 96 14 26 00 Fax: +45 96 14 26 55 [vikan@vikan.com](mailto:vikan@vikan.com)

